

Scan the QR code for more product information




Cremax Europe GmbH
Weidenweg 21H
47059 Duisburg, Germany
Email: support@icydock.com




Copyright © ICY DOCK International. All Rights Reserved. 6502421 VER.2.0

1 Package Contents • Packungsinhalt • Contenu • Contenido del paquete • 包装について • 包装説明 • 包装说明



Device



User Manual



10 x M3*4 Flat Head Screws for 2.5" HDD/SSD(Optional) (2 x Screws for Spare Parts)



6 Pin Slimline SATA to 15 Pin SATA Power Cable



4 x M2*2.5 Pan Head Screws for Ultra Slim ODD (1 x Screw for Spare Parts)




6 x M3*2.5 Pan Head Screws for Device (2 x Screws for Spare Parts)

WARNING: Please use the included screws to secure the drive(s).


2 2.5" HDD/SSD Installation • Installation einer 2.5" HDD/SSD • Installation du disque dur/SSD 2.5" • Instalación de unidad de disco duro o unidad de estado sólido de 2.5" • 2.5" HDD/SSD取付手順 • 2.5吋硬碟安裝步驟 • 2.5吋硬盤安裝步驟

2-1




Push the eject button to unlock the 2.5" drive tray.

2-2



After unlocking the drive tray, simply pull out the tray to remove from the device.


2-3



Press down the rear of the drive to align with the built-in screws on the tray.

The tray supports tool-less drive installation by utilizing the built-in screws on the tray to secure the drives. To prevent dropping your drives, please do not flip the tray upside down when there is a drive placed on it.


2-4



Insert the 2.5" drive tray into the drive slot until it locks. A 'click' sound indicates when the drive tray is properly secured.

Optional:

2 x M3*4 screws can be installed on the front underside of the tray for extra stability.



3 Ultra Slim / Slim ODD Installation • Optisches Ultra Slim / Slim Laufwerk installieren • Installation de lecteur de disque optique ultrafin • Installation de lecteur Ultra Slim ODD / Slim ODD • スリムタイプ ODD デバイスの取付手順 • 超薄型 / 薄型光碟機安裝步驟 • 9.5mm / 12.7mm 笔记本光驱安裝步驟

▼ Slim ODD installation(for 12.7mm height ODD)

ODD Cover Plate



Step-1

The removed dust cover plate can be stored on the side.



M2*2.5 screws


Step-2

Insert the Slim ODD from the front of the device.



Please use 3 x M2*2.5 screw to secure the sides and rear top screw hole. The removed dust cover plate can be stored on the side of the device as shown above.

▼ Ultra Slim ODD installation(for 9.5mm height ODD)



Insert the Ultra Slim ODD from the front of the device.



M2*2.5 screws

Please use 3 x M2*2.5 screws to secure the sides and rear bottom screw hole. The dust cover plate needs to be installed as spacer on top of the ODD bay as shown above.

